<section-header>

50 mm) at a time and requires a number of spools according to the sett of warp ends. On the Dorothy and the voyageur, the clamps are fixed directly on the beam; it holds 5" (12,5 cm) by turn. The Compact holds 15" (38 cm) per turn while on an Artisat or Inca, it holds 16" (40 cm) per rotation. On a Fanny, Mira, Nilus, Nilus II, Colonial I, Kebec or Nilart, it holds 19" (48 cm) per rotation. A sectional warp beam is especially appreciated by the weaver without a helper since the warp can be beamed easily by one person.

1" (25mm) sections			
· · · · · · · · · · · · · · · · · · ·			
6443-1001	15¾"	\$413.00	
6443-1100	24" Dt & Voy (23")	\$413.00	
6443-2000	22"	\$286.00	
6443-3000	24"	\$314.00	
6441-3000	27"	\$314.00	
6443-4000	32"	\$314.00	
6441-4000	36"	\$314.00	
6441-5000	45"	\$384.00	
6441-6000	60"	\$484.00	
6441-6720	72"	\$589.00	
6441-7000	100"	\$699.00	
6441-8000	120"	\$957.00	
2" (50mm) sections			
6442-4000	36"	\$265.00	
6442-5000	45"	\$294.00	
6442-6000	60"	\$386.00	
6442-7000	100"	\$700.00	
6442-8000	120"	\$761.00	

EXTENSION KIT TO CONVERT SECTIONAL WARP BEAM TO 1 YARD PER TURN (91 CM)



Note: <u>not</u> for the Compact and Artisat looms

6161-2000	For loom from 27" to 36" (70 - 90 cm) 12 pieces	\$61.00
6161-6000	For 45" (115 cm) loom 16 pieces + 12 blocks	\$132.00
6161-7000	For 60" (150 cm) loom 16 pieces + 12 blocks	\$132.00
6162-4000	For 100" (250 cm) loom 24 pieces + 40 blocks	\$193.00
6162-5000	For 120" (300 cm) loom 32 pieces + 56 blocks	\$215.00
6161-7200	For 72" 16 pieces + 20 blocks	\$160.00

Leclerc Looms

CA 2024

39

SECTIONAL WARPING

TENSION BOX



The tension box is used with the Sectional Warp Beam and is adjustable to fit any Leclerc floor loom. The tension is adjustable for uniform tension on all warp ends as they are wound from the spool rack to the loom.

Two open 12 threads per inch (4.8 / cm) combs allow easy threading and help guide threads into the proper section.

The tension box can also be used with an optional counter when filling bobins to give the number of meters or yards on bobbins. 6160-1000 \$204.00 Fit in breastbeam 11/2" to 31/4"



Compact Loom Tension box adaptor

This part allow the tension box to be at the horizontal position when sitting in the back breastbeam of the Compact loom 24"

6160-1020 \$132.00



CA 2024 -

40

SECTIONAL WARPING

DIVIDERS



Useful when beaming long warps. They are placed in each section every 5 or 10 yards (meters) to prevent uneven build-up of threads and keep uniform tension in the warp. They all have to be placed in the same turn

6165-10001" (25mm) sections \$26.00 / 1006165-20002" (50mm) sections \$35.00 / 100

GUIDES

A set of 8 pieces that fit the steel divisions for each section of the sectional warp beam. They prevent the warp ends from going into other sections, or from staying on top of the divisions. When the section is filled, transfer to the next section.

6166-1000 \$20.00 per set of 8





COMB FOR TENSION BOX

Any reed size available. Indicate number of dents per inch (cm).

6260-0000 \$9.00

DOUBLING STAND

Doubling stand used for twisting two or three threads together.

One tube of yarn is placed on the floor, one on the lower shelf and one on the center shelf.

Thread passes through the center of the middle and upper cones (or tubes). Thread from upper shelf then joins the two lower ones and passes through the hole in the top shelf. Hang on wall (2 screws included) $2\frac{1}{2}$ " x $5\frac{1}{2}$ " x 25" (Made of maple)

- Leclerc Looms

6360-1000 \$79.00

CA 2024 -

41